

## Clearing an Alarm

Instructions valid for Control Panel version 7.xx & POLD version 2-3.03



### FLOW/LDS ALARM

#### Step 1: Clear or Silence the Alarm

To disable the siren, press 'Silence' or 'Clear Alarm'. Water will still be off.

#### Step 2: Track the Alarm Source

Check for possible leaks (faucets, toilets, appliances).

#### Step 3: Turn Water On

Once the cause of the alarm is identified & handled, Press 'Water On' or the Water icon.

Keep an eye on the flow percentage after the valve is open.

### POLD ALARM

#### Step 1: Locate the POLD

Press Silence to disable the siren on the control panel & Locate the POLD by the number given on the panel.

#### Step 2: Reset the POLD

The unit should self-clear once moisture is not sensed. If this does not happen, open the battery compartment on the POLD and press the reset button for 1-3 seconds until silent (or remove and re-insert one battery).

#### Step 3: Turn Water On

Once the cause of the alarm is identified and handled, Press 'Water On' or the Water icon. If the system alarms again, check the POLD # after "Source:" to see if it matches the POLD that was reset. If it is different, repeat Step 1 & 2.

